

how to replace a controller without white wire ?

The white wire controls the inlet valve.



old controller:




standard controller:

From:

<https://diasys-technologies.com/waterpurifiers/> - **DiaSys Water Purifier Systems**

Permanent link:

https://diasys-technologies.com/waterpurifiers/doku.php?id=replace_controllerwithoutwhitewire&rev=1552664434 

Last update: **2019/03/15 15:40**