

how to replace a controller without a white wire ?

The white wire controls the inlet valve.




old controller:



standard controller:

From: <https://diasys-technologies.com/waterpurifiers/> - **DiaSys Water Purifier Systems**

Permanent link: https://diasys-technologies.com/waterpurifiers/doku.php?id=replace_controllerwithoutwhitewire&rev=1552664462 

Last update: **2019/03/15 15:41**