

OSMOSERS-TROUBLESHOOTING

PROBLEMS	POSSIBLES CAUSES	SUGGESTED ACTION	
- No production of purified water	indicator <i>PUMP</i> switched off	- Power switch is on OFF position.	Switch ON the device
	- The water supply of the tap closed or insufficient pressure (in that case the light " <i>SOURCE</i> " is on).	Check the water supply	
	- water hose folded or obstructed	Check that the inlet pipe is not damaged.	
- No production of purified water - Power light ON - all control light indicators OFF	On fuse is broken : - on power supply - in the controller box	Check and replace the fuses	
- Not or low purified water production - indicator <i>PUMP</i> light ON - Pump running	Pre-treatment clogged	Replace the pre-treatment filters before the RO membrane	
	Low flow of inlet water	Increase the flow of the inlet water	
	Reverse osmosis membrane clogged	Change the membrane	
- Not or low purified water production - indicator <i>PUMP</i> light ON - Pump always OFF	Pump fuse burned	Replace the pump fuse	
Light indicators <i>FULL</i> and <i>PUMP alternate</i>	Defectiveness of the high-pressure sensor or check valve.	Pressure sensor and check valve	
Lack of pressure and low flow output	- Watertank hand valve closed.	Turn ON the watertank hand valve	
	- volume of pure water need above the specification of the water purifier	Wait the watertank is filled again	
	- Lack of pressure in the pressurised watertank	Re-adjust the air-pressure of the water tank	
purified water conductivity too high	Resin saturated.	Replace resin cartridge or bottle	
- POWER & FULL indicators ON - Pump OFF - Drain flowing continuously	- Inlet solenoid valve defective	Replace the inlet solenoid valve	
Conductivity meter display OFF	Batteries out of order	Replace the batteries	

From:

<https://diasys-technologies.com/waterpurifiers/> - **DiaSys Water Purifier Systems**

Permanent link:

<https://diasys-technologies.com/waterpurifiers/doku.php?id=rotroubleshooting&rev=1554383049>



Last update: **2019/04/04 13:04**